

Installation & Maintenance Manual



P38DF Indoor

**P Series
Residential
Fireplace**

DANGER

Read and understand this manual. Improper installation, adjustment, alteration, service or maintenance can cause serious injury, property damage or even death. For assistance or additional information consult a qualified installer, service agency or the gas supplier.

WARNING

Do not store or use gasoline or any other flammable vapors and liquids in the vicinity of this or any other gas burning appliance. A fire or explosion may occur causing serious injury, property damage or even death.

DANGER



**HOT GLASS WILL
CAUSE BURNS.
DO NOT TOUCH GLASS
UNTIL COOLED.
NEVER ALLOW CHILDREN
TO TOUCH GLASS.**





A barrier designed to reduce the risk of burns from the hot viewing glass is provided with this appliance and shall be installed for the protection of children and other at-risk individuals.

NOTICE

Installer: Leave this manual with the appliance. Do not remove.
Consumer: Retain this manual for maintenance and future reference. Do not Discard.

DANGER

IF YOU SMELL GAS

-  Do not try to light any appliance.
-  Do not touch any electrical switch; do not use any phone in your building.
-  Immediately call your gas supplier from a neighbor's phone. Follow the gas supplier's instructions.
-  If you cannot reach your gas supplier, call the fire department.



NOTICE

You must read and understand this manual prior to installation, operation or troubleshooting this appliance. Please retain this owner's manual for future reference and maintenance.

Table of Contents

Instruction Manual Contents

| | |
|--|----|
| Safety Alerts..... | 3 |
| Introduction..... | 3 |
| Section A: Before You Start..... | 4 |
| Installation Checklist..... | 4 |
| Rating Plate Sample..... | 5 |
| Section 1: Installation Overview and Product Dimensions..... | 6 |
| Section 2: Framing..... | 7 |
| Clearances..... | 8 |
| Section 3: Venting..... | 9 |
| Section 3-1: Converting to Rear Vent..... | 9 |
| Section 3-2: Installing a Roof Mounted Direct Vent Termination (PVT-K-1)..... | 10 |
| Section 3-2-1: Venting Layout..... | 10 |
| Section 3-3: Installing a Wall Mounted Direct Vent Termination..... | 12 |
| Section 3-3-1: Venting Layout: Wall Mounted Termination..... | 13 |
| Section 3-3-2: Venting Components..... | 16 |
| Section 3-3-3: Heat Shields..... | 17 |
| Section 4: Wiring..... | 18 |
| CPI [Continuous Pilot Ignition] / IPI [Intermittent Pilot Ignition] Jumper Cable Installation..... | 19 |
| Section 5: Installing the Gas Line..... | 20 |
| Section 5-1: FUEL CONVERSION..... | 20 |
| Section 5-2: GAS PRESSURE..... | 20 |
| Section 5-3: GAS CONNECTION..... | 20 |
| Section 6: Finishing..... | 21 |
| Section 7: Screen Installation and Removal..... | 22 |

| | |
|--|----|
| Section 8: Installing & Removing the Door..... | 23 |
| Section 9: Installing the Accessories..... | 25 |
| Installing Optional Speckled Stones..... | 26 |
| SIT Proflame 2 Electronic Ignition..... | 29 |
| Operation..... | 29 |
| Remote Operation..... | 30 |
| Maintenance..... | 35 |
| General..... | 35 |
| Cleaning..... | 35 |
| Troubleshooting..... | 36 |
| SIT Proflame 2:..... | 36 |
| Replacement Parts:..... | 37 |
| Appendix A: Venting Terminations..... | 38 |
| Appendix B: Warranty..... | 39 |
| Appendix C: State of Massachusetts..... | 40 |

Safety Alerts

Safety Alert Key



DANGER

Indicates a hazardous situation which, if not avoided, **WILL** result in death or serious injury or property damage.



WARNING

Indicates a hazardous situation which, if not avoided, **COULD** result in death or serious injury or property damage.



CAUTION

Indicates a hazardous situation which, if not avoided, **WILL** result in minor or moderate injury.

NOTICE

Addresses practices that are important, but not related to personal injury

Introduction

Introduction

Congratulations on your purchase of a Montigo Fireplace.

With over 30 years of experience, Montigo is committed to **providing you with a gas fireplace that is not only a beautiful addition to your space, but that is also designed and manufactured to the highest safety, reliability and engineering standards.**

We strongly encourage you to read and carefully follow the instructions laid out in this Installation, Operation and Maintenance Manual and retain it for your future reference. Pay special attention to all cautions, warnings, and notices throughout this manual intended to ensure your safety.

This manual covers installation, operation and maintenance. **Lighting, operation and care of this fireplace can be easily performed by the homeowner. All installation and service work should be performed by a qualified or licensed installer, plumber or gas fitter as certified by the state, province, region or governing body where the fireplace is being installed.**

This installation, operation and maintenance manual is applicable to the models described to the right. Refer to your rating plate to verify included options.



CAUTION

Young children should be carefully supervised when they are in the same room as the appliance. Toddlers, young children and others may be susceptible to accidental contact burns. A physical barrier is recommended if there are at risk individuals in the house. To restrict access to a fireplace or stove, install an adjustable safety gate to keep toddlers, young children and other at risk individuals out of the room and away from hot surfaces.

| MODEL | Natural Gas | Liquid Propane | Gas Rating (BTU hr) | Linear Burner w/ Glass media Accessories | SIT Electronic Ignition |
|---------|-------------|----------------|---------------------|--|-------------------------|
| P38DFNI | X | | 25,000 | X | X |
| P38DFLI | | X | 25,000 | X | X |

Warranty and Installation Information: (See Appendix B)

The Montigo warranty will be voided by, and Montigo disclaims any responsibility for the following actions:

- **Modification of the fireplace and/or components** including Direct-Vent assembly or glass doors.
- **Use of any component part not manufactured or approved by Montigo in combination with this Montigo fireplace system.**
- **Installation other than as instructed in this manual.**

Consult your local Gas Inspection Branch on installation requirements for factory-built gas fireplaces. **Installation & repairs should be done by a qualified contractor.**



Installation

Section A: Before You Start

IMPORTANT MESSAGE: SAVE THESE INSTRUCTIONS

The P38DF* Direct Vent fireplace must be installed in accordance with these Instructions. Carefully read all the Instructions in this manual first. Consult the Local Gas Branch to determine the need for a permit prior to starting the installation. It is the responsibility of the installer to ensure this fireplace is installed in compliance with the manufacturers instructions and all applicable codes.

BEFORE YOU START:

NOTICE

Installation and repairs should be done by an authorized gas fireplace service technician. The appliance should be inspected before use and at least annually by a professional. More frequent cleaning may be required due to excessive lint from carpeting, bedding material, etc. It is imperative that control compartments, burners and circulating air passageways of the fireplace are kept clean.



CAUTION

Due to high operating temperatures, this appliance should be located out of traffic & away from furniture and draperies.

Children and adults should be alerted to the hazards of the high surface temperature, which could cause burns or clothing ignition.

Young children should be carefully supervised when they are in the same room as the appliance.

Clothing or other flammable materials should not be placed on or near the appliance.



DANGER

When this appliance is installed directly on any combustible material other than wood flooring, it must be installed on a metal or wood panel extending the full width and depth of the appliance or a fire will occur causing serious injury, property damage or even death.

Installation Checklist

- Determine the desired install location of your fireplace.
- See Section 1, Dimensions on Page 5, and refer to the Framing Section 2 for details.
- Select the location of your termination and resulting vent run.
- Your selected termination location must be the highest point in the Direct Vent installation.
- Should it be impossible to meet the venting requirements laid out in Section 3: Venting, please contact a local Montigo dealer regarding the use of a Montigo Power Vent.
- Lay out the Vent run; calculating the required elbows and straight runs of 5"/8" flex and/or rigid pipe.
- Layout Electrical Requirements Refer to Section 4: Wiring, for Details.
- Refer to Section 5: Installing the Gas Line, for details on the gas connection and access.
- Refer to local codes and guidelines for installation requirements.
- Installation and repairs should be done by a qualified contractor and must conform to:

- Installations in Canada must conform to the local codes or in the absence of local codes to the current version of Natural Gas and Propane Installation Code, CSA B149. Electrical Installations must conform to the local codes or, in the absence of local codes, to the current version of Canadian Electrical Code, CSA C22.1.1

- Installations in the USA must conform to the local codes or in the absence of local codes to the current version of National Fuel Gas Code, ANSI Z223.1/NFPA 54. Electrical Installations must conform to the local codes or, in the absence of local codes, to the current version of the National Electrical Code, ANSI/NFPA 70. See Appendix C for installation within the State of Massachusetts.

WARNING

A barrier designed to reduce the risk of burns from hot viewing glass is provided with this appliance and shall be installed for the protection of children and other at-risk individuals.

If the barrier becomes damaged, the barrier shall be replaced with the manufacturer's barrier for this appliance.

WARNING

Any safety screen, guard, or barrier removed for servicing an appliance must be replaced prior to operating the appliance.

Installation



Rating Plate Sample

Do Not Remove This Label
N'enlevez Pas Cette Étiquette

Type: XULPIE L

Model No. Modèle: P38DF-F

Serial No.: 2-150225-238052

Manufacturer / Fabricant: Canadian Heating Products Inc., Langley BC, (www.montigo.com)
Montigo DeRay Corp., Ferndale, WA, (www.montigo.com)

Tested To / Examiné À: **ANSI Z21.88-2014 / CSA 2.33-2014**

Electrical Rating / Estimation Électrique: With Elec. Ign, 115V / 1 Ph./ 60 Hz./less than 12A

Altitude Rating / Estimation D'Altitude: N & H (0 - 4500 ft. / 0 - 1371 m.)

Fuel Type / Type De Carburant:

| | Max. Input BTU/H | Min. Input BTU/H | Output / Rendement BTU/H | Orifice Size / Taille D'Orifice Front/Avant Rear/Derrière |
|--|---------------------|---------------------|--------------------------------|--|
| <input checked="" type="checkbox"/> N - Natural Gas / Gaz Naturel | 25,000 | 17,000 | N/A | 2@51 DMS / N/A |
| <input type="checkbox"/> LP - Propane / Gaz Propane | 25,000 | 21,000 | N/A | 2@58DMS / N/A |

Vented Gas Fireplace Heater
Not for use with solid fuel. / Pas pour l'usage avec le combustible solide.
Not for use with air filters. / Pas pour l'usage avec des filtres à air.

For Indoor Use Only

| *Clearance to Combustibles *Dégagements Aux Combustibles | |
|---|---------|
| Sides/Côtés: | 0" |
| Back/Derrière: | 0" |
| Top-Top Vent/Du Haut-Évent Du Haut: | 17 1/2" |
| Top-Rear Vent/Du Haut-Évent Arrière: | 9" |
| Floor/Plancher: | 0" |
| Mantel/Manteau: | 4 |
| Recess Depth/ Profondeur D'Encadrement: | 20 1/4" |

FOR USE WITH GLASS DOORS AND SCREENS CERTIFIED WITH THE APPLIANCE ONLY
Pour utilisation avec portes de verre and écrans de certifiés avec l'appareil seulement

***Refer to installation manual for more information.**
*Référez-vous au manuel d'installation pour plus d'information.

Figure A: Rating Plate for P38DF-F IPI Electronic Ignition



Installation

Section 1: Installation Overview and Product Dimensions

Please review the Installation Checklist on Page 4 for general information on preparing for a successful installation of your fireplace.

The P38DF* fireplace may be installed in any location that maintains proper clearances to air conditioning ducts, electrical wiring and plumbing. Safety, as well as efficiency of operation, should be

considered when selecting the fireplace location. Try to select a location that does not interfere with room traffic, has adequate ventilation and offers an accessible path for Direct Vent installation.

The fireplace dimensions are shown below:




Figure 1. Fireplace dimensions, (Tolerance $\pm \frac{1}{8}"$).

Installation



Section 2: Framing

1). Frame in the enclosure for the unit with framing materials. The framed opening for the assembled fireplace is 37 3/4" wide, x 41 1/4" high x 20 1/8" deep, see Figure 2.

NOTE: When constructing the framed opening, please ensure there is access to install the gas line when the unit is installed. See Figure 21.




Figure 2. Framing dimensions, (Straight wall & Corner Installation).




Figure 3. Combustible Framing for shelves over the fireplace, Rear vent. **Note: Rear vent available for Natural Gas only.**




Figure 4. Combustible Framing for shelves over the fireplace, Top vent.




Figure 5. Non Combustible Framing for Top Vent or Rear Vent, with alcove. **Note: Straight through the wall rear vent available for Natural Gas only.**

Note: Images are shown without screens for clarity purposes. However, your fireplace should not be operated without proper installation of screens.



Installation

Clearances

When installing a shelf over the top of the fireplaces, the following guidelines must be adhered to:

For Rear Vent applications, the minimum clearance is 0" from the rear of the fireplace to a wall, or any combustible materials, and 9" clearance from the top of the fireplace to the underside of any combustible shelf materials.

For Top Vent applications, the minimum clearance is 0" from the rear of the fireplace to a wall, or any combustible materials, and 17 1/2" to the underside of any combustible shelf materials.

1" clearance is maintained on sides and bottom of vent runs and 2" above horizontal vent runs to any combustible material.

| MODEL | Top - Rear vent † | Top - Top vent † | Rear | Sides | Floor | Mantel |
|--------|-------------------|------------------|------|-------|-------|--|
| P38DF* | 9" | 17 1/2" | 0" | 0" | 0" | See Section 6 Finishing around the fireplace |

† NOTE: Clearance from top of fireplace to a ceiling within the fireplace enclosure.

Installing The Standoffs

To avoid elevated mantel temperatures, all P38DF* gas fireplaces are required to have the supplied standoffs installed. The fireplace is supplied with two standoffs. Bend and install these standoffs on top of the fireplace ensuring that the height of the standoff maintains a 7 1/2" clearance.




Figure 6. Installing standoffs

Installing the Nailing Flange Extension

Before installing the supplied nailing flange extension, fold tabs at bottom of nailing flange to a 90 degree angle.



Figure 7. Bottom of Nailing Flange Extension



Figure 7a. Bottom of Nailing Flange Extension with tab folded at 90 degree angle



Figure 7b. Insert folded tabs into slots above the front of the fireplace




Figure 7c. Securing the Nailing Flange Extension.

The supplied nailing extension must be placed along the top edge of the fireplace and securely fastened into place, as shown in figure 7c. Note: The nailing flange extension can be substituted with a piece of NON-Combustible material of the same size and thermal characteristics, ie: cement board or equivalent.

Installation



Section 3: Venting

Montigo supplies a variety of direct venting and termination options. The direct vent termination location **MUST** be selected such that it is the highest point in the venting assembly. It should also be selected such that it provides the shortest vent run possible. Should it be impossible to ensure that the termination is the highest point or to meet the venting guidelines laid out below please contact your Montigo dealer to discuss power venting options.

NOTES FOR PLANNING VENTING:

- Venting can originate from the unit through the top or through the rear
- Venting can terminate through the roof or through an exterior wall.
- Refer to Appendix A - Termination Locations to ensure the planned termination location is acceptable.
- Once the termination location has been established, refer to the appropriate section below for installation details
- **All fireplaces shipped from the factory are Top vent.**
- Silicone application is NOT required when joining Montigo vent pipes and components.




Figure 8a. Flue cover and collar installation, Rear Vented fireplace.

Note: Images are shown without screens for clarity purposes. **However, your fireplace should not be operated without proper installation of screens.**

Section 3-1: Converting to Rear Vent

Use the following instructions to convert an P38DF* for Rear Vent use:

1. Remove the Rear flue cover and gasket (5" and 8") on the flue outlet, as shown in Figure 8.
2. Next, Remove the Top flue collar's (5" and 8") on the flue outlet, as shown in Figure 8.
3. Install the (removed) Rear flue cover and gasket material, to the Top vent outlet. Fasten the cover with included hardware, as illustrated Figure 8a.
4. Install the (5" and 8") collars to the rear vent outlet using the included hardware, as illustrated Figure 8a.




Figure 8. Flue cover and collar removal, Top Vented fireplace.



Installation

Section 3-2: Installing a Roof Mounted Direct Vent Termination (PVTk-1)

This section applies to installations where the direct vent termination will be roof mounted.

Section 3-2-1: Venting Layout

Selection of components and details of venting lay out should adhere to the following guidelines:

- The maximum termination point is 32' above the fireplace (NOTE: if the maximum termination height is used, the flame pattern may be affected).
- The Vertical termination must be a minimum 2' higher than where the termination exits the roofing materials, (asphalt shingles, cedar shakes, etc). This distance should be measured from the high side of the roof slope where the flue flashing intersects the roofing materials. (see Figures 9 to 9c).
- Termination location must be a minimum 6' from a mechanical air inlet.
- For a more detailed diagram of allowed termination locations, see Appendix A.
- A maximum of two offsets (each offset is made up of 2-90° bends) may be made for vertical vent runs.
- Firestops must be installed as required by National & local codes
- Ensure all horizontal runs are supported with a minimum of 3 supports per 10' of venting.
- Install all roof flashing and storm collars as shown.

Roof mounted Terminations

The following details are some possible configurations for Roof mounted terminations.




Figure 9. Top vent, Roof mounted termination with no offset in vent run.




Figure 9a. Top vent, Roof mounted with 1 offset (1 offset= two 90° bends).




Figure 9b. Top vent, Roof mounted with 2 offsets (1 offset= two 90° bends).

Installation




Figure 9c. Rear vent, Roof mounted venting (1 = 90° bend).

Note: Images are shown without screens for clarity purposes.
However, your fireplace should not be operated without proper installation of screens.



Installation

Section 3-3: Installing a Wall Mounted Direct Vent Termination

This section applies to installations where the direct vent termination will be wall mounted.

1). Installation of Termination with built in frame

A Termination with a Built-In Frame is installed during framing of a structure.

1. Frame the termination opening to 11" x 11".
2. Install exterior sheathing to the structure framing.
3. Fasten the termination to the sheathing using a minimum of 4 screws.




Figure 10. Installing a PTO4-F termination.

2). Installation of termination frame at time of framing

Terminations with a MSR frame allow the installation of the frame prior to installation of the termination.

1. Frame the termination opening to 12" x 12".
2. Secure the MSR Frame to the exterior sheathing of the structure.
3. Fasten the termination to the MSR Frame using a minimum of 4 screws.




Figure 10a. Installing a PTO termination with the MSR frame.

3). Installation of termination frame at time of framing in Masonry

Terminations with a BSR frame allow the installation of the frame in masonry prior to the installation of the termination

1. Frame the BSR opening to 12" x 12".
2. Secure the BSR Frame to the exterior sheathing of the structure.
3. Fasten the termination to the BSR Frame using a minimum of 4 screws.




Figure 9b. Installing a PTO termination with the BSR frame.

4). Installation of termination from inside structure

A Termination with a MOSR Frame is installed from the inside of the structure. These are commonly used in high-rise construction.




Figure 10c. Installing a PTO termination with MOSR frame.

1. Frame the MOSR opening to 12" x 12".
2. Fasten the MOSR frame to the interior side of the studs, concrete, or finished wall construction using a minimum of 4 screws.
3. Insert the termination into the MOSR frame as shown here, (from the inside) and attach to the MOSR by installing a min. quantity of 4 bolts into the threaded nuts on the MOSR Frame.

5). Installation of a termination shield for Vinyl Siding

The VSS Termination shield is installed when the exterior of a structure is clad with Vinyl siding. It is placed directly above, and on-center with the termination.




Figure 10d. Installing the VSS Vinyl Shield.

Installing Heat Guards over Terminations is recommended in installations where the termination is located within 7' feet above grade, or above a pedestrian walkway, and may be Required by code in Public areas.




Figure 11. Installing a PTO termination heat guard.

1. Ensure that the two long mounting brackets are facing the bottom of the termination. (See inset). This will provide more heat protection at the top of the termination, where temperatures are highest.
2. Attach to the faceplate of the termination using four sheet metal screws.

Installation



Section 3-3-1: Venting Layout: Wall Mounted Termination

Selection of components and details of venting layout should adhere to the following guidelines:

- Vent terminations must not be recessed in walls or siding.
- For Heat Shield requirements see Section 3-3-3 on page 16.
- Once the proposed venting layout has been determined refer to Figure 12, 12a, 15, or 15a to ensure the layout is acceptable.

Notes Wall Mounted Terminations: TOP VENT

- All measurements for vertical or horizontal runs are measured from center of the vent pipe.
- Venting runs must fall within the limits set by the venting graph, see Figure 12 or 12a.

Wall mounted Terminations

The following details are some possible configurations for Wall mounted terminations. See below.

The Venting Graph:

Measure the vertical height from the fireplace hearth to the centre of the termination and the horizontal run from the fireplace flue collar to the wall flange of the termination. Plot on the Venting Graph Figure 12 or 12a with an 'X'.

If the 'X' falls on or above the top boundary of the shaded area, the installation is acceptable.

Example A: (Acceptable Installation)

If the vertical dimension from the hearth is 120" and the horizontal run to the wall flange of the vent termination is 144", this would be an acceptable installation.

Example B: (Unacceptable Installation)

If the vertical dimension from the hearth is 36" and the horizontal run to the wall flange of the vent termination is 84", this would not be an acceptable installation.

Example C: (Unacceptable Installation)

If the vertical dimension from the floor of the fireplace is 60" and the horizontal run to the wall flange of the vent termination is 144", this would not be an acceptable installation.




Figure 12. P38DF* LP Top Vent Venting Graph for wall mounted terminations.




Figure 12a. P38DF* NG Top Vent Venting Graph for wall mounted terminations.




Figure 13. Top Vented, wall mounted installation with one 90° bend. The vent run must comply with Venting Graph for Top vent, wall mounted terminations, Figure 12 or 12a.




Figure 13a. Top Vented, wall mounted Multi-elbow installation. See Venting Graph for Top vent, wall mounted terminations, Figure 12 or 12a.



Installation

45° Corner Installation.

Attach an PEL-45 (45° elbow) directly onto the flue collar. Cut the PXT-20 to suit, and attach it to the PEL-45. Slide the fireplace into position and attach to the termination.




Figure 14. Corner (Rigid) installation. (NG Models Only)

Note: Images are shown without screens for clarity purposes. However, your fireplace should not be operated without proper installation of screens.

45° or less Corner Installation.

Use a PTO-4 termination and an PFL-1 or PFL-2 (12" or 24" compressed length) and a frame, if appropriate. Flex may be turned to obtain desired degree of angle required but must not exceed 45°.




Figure 14a. Corner (Flex) installation. (NG Models Only)

Note: Through the wall venting kits are also available for both the Straight and the Corner Installation. The Kit includes a heat shield, a PFL-18 (f/f) flexible pipe, and a termination with or without a mounting frame.

IMPORTANT:

Corner Installation is available for P38DF Top Vent Units Only. Ensure minimum Vertical Venting Height of 40" is maintained in corner installations.

Installation



Notes Wall Mounted Terminations: REAR VENT

- All dimension lengths for vertical or horizontal runs are measured from center of the vent pipe.
- Venting runs must fall within the limits set by the venting graphs, see Figure 15 or 15a.
- Fireplace must be converted to Rear Vent configuration prior to running vent, see Figure 8 and 8a.

The Venting Graph

Measure the vertical height from the fireplace hearth to the centre of the termination and the horizontal run from the fireplace flue collar to the wall flange of the termination. Plot on the Venting Graph Figure 15 or 15a with an 'X'.

If the 'X' falls on or above the top boundary of the shaded area, the installation is acceptable.

Example A: (Acceptable Installation)

If the vertical dimension from the hearth is 120" and the horizontal run to the wall flange of the vent termination is 138", this would be an acceptable installation.

Example B: (Unacceptable Installation)

If the vertical dimension from the hearth is 36" and the horizontal run to the wall flange of the vent termination is 84", this would not be an acceptable installation.

Example C: (Unacceptable Installation)

If the vertical dimension from the floor of the fireplace is 60" and the horizontal run to the wall flange of the vent termination is 144", this would not be an acceptable installation.




Figure 15. Rear Vent Venting Graph for NG wall mounted terminations.




Figure 15a Rear Vent Venting Graph for LP wall mounted terminations.




Figure 16. Straight run, Rear Vented, wall mounted termination. Note: Straight through the wall rear vent available for Natural Gas only.




Figure 16a. Rear Vented, wall mounted Multi-elbow termination installation for NG or LP. Installation must comply with the Venting Graph for Rear vent, wall mounted terminations, Figure 15 or 15a.



Installation

Section 3-3-2: Venting Components

The following components and associated Montigo part numbers for installation of a roof or wall mounted termination. Use only Montigo Vent Components. Use of non-Montigo parts will **VOID the warranty and may impede operation of the fireplace.**

| | |
|--------------------------|--|
| A - Termination | PTO4 (3" Length) PTO4F (3" Length) PVTK1SS |
| B - Frame Kits | MSR (Stucco Frame) MOSR (Stucco Frame) BSR-4 (4" Brick Frame) BSR-6 (6" Brick Frame) |
| C - Flex Sections | PFL - 1 (12" f/f Section) PFL - 18 (18" f/f Section) PFL - 2 (24" f/f Section) PFL - 3 (36" f/f Section) PFL - 4 (48" f/f Section) PFL - 6 (72" f/f Section) |
| D - Rigid Sections | PXT - 5 (5" f/f Section) PXT - 10 (10" f/f Section) PXT - 20 (20" f/f Section) PEXT - 1 (12" f/m Section) PEXT - 2 (24" f/m Section) PEXT - 3 (36" f/m Section) PEXT - 4 (48" f/m Section) PEXT - 6 (72" f/m Section) |
| E - Elbows | PEL-90MM (m/m 90° Elbow) PEL-90FF (f/f 90° Elbow) PEL-90FM (f/m 90° Elbow) PEL-45FM (f/m 45° Elbow) |
| F - Support Ring & Plate | PSPXT-8 |
| G - Firestop | FS-8 |
| H - Roof Flashing | PRF-7 (1/12 - 7/12 pt.) PRF-12 (7/12 - 12/12 pt.) |
| I - Heat Shield | RHS101 |
| J - Heat Guard | MTKOG |

Connection and installation of the vent components should adhere to the following guidelines:

- **Use any combination of rigid and flex pipe as required and in any orientation** (Male connectors can face in any direction).
- Flex sections may be stretched up to 50% of their total length (e.g. a 24" section maybe stretched to 36").
- Connect all vent sections using a minimum of three sheet **metal screws on the outer pipe flue.**
- Ensure the pipe ends male to female slide in a minimum of 1 1/2" of overlap.
- Ensure all horizontal runs are supported with a minimum of 3 supports per 10' of venting.
- When hanging/supporting venting, ensure that 1" clearance is maintained on sides and bottom of vent runs and 2" above horizontal vent runs to any combustible material.
- Rigid pipe may be cut less than half way from the female end only.
- Ensure when cutting sections of rigid pipe to maintain integrity of internal supports.
- Place the springs, supplied with the pipe kit, between the outer and inner pipes to keep the pipes separate and avoid any possible hot spots.
- **Montigo recommends the use of a flex section for the final pipe connected directly to the fireplace offering greater flexibility of installation and absorption of movement.**
- Firestops must be installed as required by National & local codes.
- Montigo recommends that all exterior corners and joints be sealed with exterior caulking. However, we encourage you to **consult your Building Envelope Engineer or Waterproofing Consultant** for further recommendations.

IMPORTANT:

Please Refer to your Building Envelope Engineer or Waterproofing Consultant for a review of ALL penetrations through exterior walls or the roof.

Installation



Section 3-3-3: Heat Shields

Installing a Wall Mounted RHS8 Heat shield

The RHS8 Heat shield CANNOT be used when the Termination is **WITHIN (36" Min. horizontal and 60" Min. vertical) from the fireplace, or directly off the rear of the fireplace, as shown figure 17a.** The RHS101 Heat Shield (Figure 18c and 18d) MUST be used within the noted dimensions.

To install the RHS8, frame an opening in combustible construction, Figure 17 below. Slide the Heat shield in place over the vent pipe **which attaches to the fireplace.** After the fireplace and vent pipe has been installed, clearances should match the dimensions in Figure 17a.




Figure 17. RHS8 Installation. (Install by sliding over vent pipe where it passes through the combustible construction).




Figure 17a. RHS8 Installation. (Minimum requirements).

Note: Images are shown without screens for clarity purposes. However, your fireplace should not be operated without proper installation of screens.

Installing a Wall Mounted RHS101 Heat shield.

The RHS101 Heat shield **MUST** be used where the RHS8 Termination (Figure 17 and 17a) CANNOT be used. Use the RHS101 where any of the dimensions are within the parameters shown, figure 17a.

To install the RHS101, Slide the Inner Section over the vent pipe that will connect to the fireplace. Then fasten the vent pipe to the back of the fireplace with a minimum of three sheet metal screws. From the outside slide the RHS101 outer section on see Figure 18. To complete the installation fasten the Heat Shield Outer Section & Termination frame to the structure Figure 18a.




Figure 18. RHS101 Installation. (Install by sliding Outer Section over vent pipe where it passes through the combustible construction).




Figure 18a. RHS101 Heat Shield after sliding the outer section in place.




Figure 18b. RHS101 Installation.



Installation

Section 4: Wiring




Figure 19. Wiring diagram for P38DF with SIT Proflame 2 Electronic Ignition




Figure 20. Electrical connection access.

NOTE: If any of the original wire supplied with the appliance is replaced, it must be replaced with the same type, or its equivalent.

Installation



CPI [Continuous Pilot Ignition] / IPI [Intermittent Pilot Ignition] Jumper Cable Installation

“Why use CPI mode”?

There are several reasons why you may choose to use CPI mode. When a flue is cold it can be difficult to light the appliance. It can take a bit of time (particularly on tall vents) to initialize vent action. This can result in “lifting” or “ghosting” of the flames during the first two to three minutes of operation. It is also possible to encounter times when the fireplace fails to light successfully. The fireplace will then attempt to re-light a second or third time depending on prevailing temperatures or altitude. When in CPI mode the pilot also keeps the system warm. During a “cold” start, condensation will normally form on the inner glass surface of the door. This condensation will quickly dry, however, the condensation tends to run down the glass and cause some streaking. CPI mode helps to resolve this issue. If CPI mode is used during the winter months the energy it takes to run the pilot is partially recovered as heat into the building, so it does not waste as much energy as running a pilot in the off season.

A connector is supplied with this unit that can be plugged into the controller. This Jumper Cable gives the Remote Control the ability to operate the CPI / IPI switch and set the unit to operate in either condition. CPI means “Continuous Pilot Ignition” or “Standing Pilot” as it is commonly known. IPI means “Intermittent Pilot Ignition”, which only initializes the pilot when you are going to be using the appliance.

The difference between IPI and CPI:

IPI (Intermittent Pilot Ignition) Mode: is a fuel saving mode in which the pilot is only used when the main burner is on.

CPI (Continuous Pilot Ignition) Mode: The Pilot runs continuously even when the main burner is off.

Installing the CPI Jumper Cable

- 1). Remove the door and valve blind.



Figure 21.

- 2). Remove the bag containing the Jumper Cable from the wire harness connected to the controller as shown in Figure 21.




Figure 21a.

- 3). Find the corresponding plug attached to the control wire harness and connect the CPI jumper.



Figure 21b.

- 4). See operation section to turn remote into CPI mode.



Installation

Section 5: Installing the Gas Line

Section 5-1: FUEL CONVERSION

- n Verify that your fireplace is compatible with your available gas type. (Natural Gas or Propane shown by "N" or "L" in your model number)
- n If gas type is not compatible, contact your local Montigo representative.
- n Conversion kits must be installed by a qualified service technician.

Section 5-2: GAS PRESSURE

- n Optimum appliance performance requires proper input pressures.
- n Gas line sizing requirements will be determined in ANSI Z223.1/NFPA 54 National Fuel Gas Code in the USA and CAN/CGA B149.1 in Canada.

Pressure requirements are:

| Gas Pressure | Natural Gas | Propane |
|------------------------|-------------|------------|
| Minimum inlet pressure | 5.5in. w.c. | 11in. w.c. |
| Manifold pressure | 3.5in. w.c. | 10in. w.c. |

- n The manifold outlet pressure is set from the factory to the appropriate pressure but should be verified.
- n To check pressures, control valves have a provision to remove a 1/8" N.P.T. plug to be fitted with a hose barb.
- n Montigo requires a service shut off valve be located in an accessible location to isolate the gas supply.
- n Only install gas shut-off valves approved for use by the state, province, or other governing body in which the fireplace is being installed.

Section 5-3: GAS CONNECTION

- n See Figure 22 for location of gas line access.
- n Flexible gas connectors must not exceed 3 feet in length, unless allowable within local regulations.
- n Connect incoming gas line to the 1/2" or 3/8" gas inlet port.
- n Purge all air out of gas line.
- n Check appliance connection, valve and valve train under normal operating pressure with a commercially available leak check solution.

DO NOT USE A FLAME OF ANY KIND TO TEST FOR LEAKS.

NOTICE

When pressure testing the fireplace, Gas line, and input system follow the appropriate local codes or your area. DO NOT connect the fireplace to pressures in excess of 1/2lb. This will damage the gas control valve.




Figure 22. Gas line access.



WARNING

When installing the fireplace - gas lines, fittings, accessories or any other objects cannot impede the proper movement of the door buckles.

WARNING:

An inspection of the explosion relief flappers and door MUST be made prior to lighting the fireplace. A faulty seal on the door gasket and/or explosion ports will result in products of combustion leaking into the living space and may result in carbon monoxide poisoning.

Installation



Section 6: Finishing

Finishing Around the Fireplace

Non-combustible mantels and mouldings may be safely installed **over the top and on the front of the fireplace provided that they do not project beyond shaded area shown in Figure 22.**

Fireplace Facing

When sizing the finish material for your fireplace, it is important to remember the following: THE OPENING MUST NOT BE OBSTRUCTED IN ANY WAY - to do so restricts the air supply for the control compartments and heat exchanger it also prevents access for servicing controls.

The face of the fireplace may be painted to match the room decor, provided you use a heat-resistant paint. Decorative facing must not extend past the fireplace opening at all, because it will interfere with the access to retainers for removal of glass door.




Figure 23. Combustible mantels and facings.

CAUTION

Glass doors on gas fireplaces are **extremely hot** while the fireplace is on and remain hot even after the fireplace has been turned off. Safety screens are available and can reduce the risks of severe burns. Please keep children away from the fireplace at all times.

CAUTION

We recommend careful consideration be given to the effects of elevated mantel temperatures which may be in excess of product design, for example: candles, plastic or pictures. This can cause melting, deformation, discoloration or premature failure of T.V. radio, and other electronic components.

WARNING!

When covering the upper metal portion of the fireplace, up to 4" (as shown, Fig.23) with a non-combustible material Please Note: The decorative facing materials may be subject to temperatures in excess of 250° F. This should be considered when selecting facing materials.

Mantels & Surrounds

NOTE: National Canadian Gas Association mantel test requirements are for fire hazard prevention to combustible materials.

New technology, to meet consumer and government demands for the wise use of energy, has prompted us to manufacture many models of fireplaces which are hot, fuel and energy efficient.

Please be aware; temperatures over the mantel will rise above normal room temperature and walls above fireplace may be hot to touch.

Side wall clearances are 3". Combustible surrounds may be installed with 3" clearance to the side of the fireplace as shown in Figure 23a.




Figure 23a. Combustible surrounds.



Installation

Section 7: Screen Installation and Removal

Removing / Attaching Screens:

To Remove Screens:

Grasp each top outer corner of the screen with your thumb and finger and pull towards yourself. When the upper Screen Studs are free, lift the screen at an angle from the lower slots from which the Screen Bottom Tabs are held. Place the screen in a safe place.

To Install Screens:

Hold the screens at an angle away from the fireplace, and locate the Screen Bottom Tabs at the lower corners of the screen. Place the screen into the Screen Tab Receptacles in the lower section of the fireplace.

Make sure the tabs and screens are lowered all the way down into the Screen Tab Receptacles on the fireplace. Then, push each Upper Screen Stud on the top corners of the screen into the Upper Screen Stud Receptacles in the fireplace.




Figure 24a. Screen Door Numbers (Replacement Parts)




Figure 24b. Screen Installation and Removal

Replacement Screens:

For replacement part order numbers, please refer to section "Replacement Parts:" on page 30.

Note: Do not operate fireplace without all screens in place.

NOTICE

Do not use ammonia based or abrasive cleaners on the glass, they will permanently etch the surface. Use an approved gas fireplace glass cleaner such as Kel-Kem or White off.

Installation



Section 8: Installing & Removing the Door

Removing the door:

The P38DF* doors are removed in a few simple steps. Follow these instructions below to remove the Horizontal access panel, unlatch the door buckles and, remove the door. Replace in reverse order.

WARNING

When reinstalling door(s), always make sure all door buckles are properly hooked and fully engaged.

Step 1: Remove the Horizontal Access Panel:

Remove the Horizontal cover by placing fingers in both finger holes, then pushing away from you and lifting out. Place it aside during maintenance or cleaning. Install in reverse order.



Figure 25. Removing and installing the Horizontal Access Panel

Step 2: Locate the Door Buckles:




Figure 25a. Locate the door buckles.



Figure 25b. Door buckle Tool

Step 4:

Firmly grasp hand-hold end of Door buckle tool and place the machined end in the slot under door frame. (as shown)




Figure 25c.

Step 5:

Ensure the tool is firmly in the lower end of the slot, (as shown), Then pull toward you (Caution: hold the tool securely).




Figure 25d.

Step 6:

Pull hard if necessary to release the spring tension. (Caution: The latch springs back with force, hold the tool securely).



Figure 25e.

Step 7:

Remove the tool from the latch slot. Ensure the latches are hanging freely, the hook end is released from the bottom of the door. (Repeat all 4-steps for the remaining latches).




Figure 25f.



Installation

Step 8: Removing the Door:

Grasp the Door on either side, usually midway and lift upward, **lift the door carefully up and away from the front of the fireplace.** See Figures 25g. Place the Door aside in a safe place while maintenance and / or cleaning is being performed.




Figure 25g. Removing and installing the glass doors.

Installing the Door:

To install the door, hook the top edge of the door frame into place. Lower the door into position and follow the previous steps shown in reverse order.



WARNING

When installing the fireplace - gas lines, fittings, accessories or any other objects cannot impede the proper movement of the door buckles.

Installation



Section 9: Installing the Accessories

Installing the Firestones

The **P38DF*** is supplied with firestones. Remove the Door as shown in the previous Instruction. Follow these instructions to ensure all parts are removed or replaced as required. Once the Trim and glass door is removed place the firestones randomly across the pan and the burners as described in **Figure 26 to 26f**.

Note: Only cover the burner with one layer of designer firestones.



Figure 26. Up-lighting glass in package.



Figure 26a Place the up-lighting glass in the burner tray.




Figure 26b Installation of the firestones. (Ensure **ONLY** one layer of firestones cover the surface).




Figure 26c. Spreading the firestones evenly and make sure there are no firestones covering the pilot .



Figure 26d. Completed firestone installation.



Figure 26e. Completed firestone installation. (Note: **DO NOT** place **ANY** firestones on top of the pilot cover).



Figure 26f. Gas fireplace with firestones surrounding burner tray.



CAUTION!

If the firestones are not placed properly (**ONE LAYER ONLY**), on burners excessive sooting will result. The firestones will get very hot while the fireplace is in operation, and should not be handled until cool.



WARNING!

If the pilot cover is covered with firestones it may result in delayed ignition and/or damage to the appliance and/or surrounding property.



Installation

Installing Optional Speckled Stones

[RR250SS]

Once the glass door has been removed as shown in the previous section, place the speckled stones evenly across the pan and burner. Ensure stones do not overlap too much as this will effect the flame pattern, see **figure 26g**. **DO NOT** cover the pilot with stones, see **figure 26h**.



Figure 26g. *Evenly placed speckled stones*



Figure 26h. *Ensure the stones DO NOT cover the pilot.*

Installation



Installing Optional Speckled Stones

The P38DF* has the option of installing a drift wood log set. Once the firestones or speckled stones have been installed the log set can be installed.

Ensure logs are securely placed and will not tip or fall. Remove media where logs touch the burner tray to ensure a more secure position. Lean the logs against the back panels. NO LOGS SHOULD LAY ACROSS OR OVER TOP OF THE BURNER PORTS ON THE SURFACE OF THE BURNER.

Step 1. Remove the glass door as described in the previous section. See **Figure 25 - 25g**.

Step 2. Ensure selected media is installed per instruction as per **Figures 26 - 26h**.

Step 3. Unpack the logs and handle with care.



Figure 27. LGS58




Figure 27a. LGS59

Step 4. Place Log 3 from LGS58 in the back right corner of the burner tray. Ensure log does not cover ports. Place Log 2 of LGS58 on top of log 3. See **Figure 27b**.




Figure 27b.

Step 5. Place Log 5 from LGS58 on top of Log 2. Place Log 1 from LGS58 on top of log 2, see **figure 27c**



Figure 27c.



Figure 27d.

Step 6. Place log 6 of LGS59 across of log 1 of LGS58, see **figure 27e**.



Figure 27e.



Installation

Step 7. Place log 5 from LGS59 in the back left corner of the burner, behind the pilot. Place Log 4 from LGS58 on top of log 5. Use stones to help stabilize log 4. See **figure 27f and 27g.**



Figure 27f.



Figure 27g.

Step 8. Place log 2 from LGS59 in front of pilot. Place log 3 from LGS59 on top of log 2.




Figure 27h.

Step 9. Place log 1 from LGS59 on top of log 4 from LGS58. Place log 6 from LGS58 on top of log 4 from LGS58 and log 2 from LGS59. See **figure 27i.**



Figure 27i.

Step 10. Place log 4 of LGS59 in front of the ports to the right of log 5 from LGS58. See **figure 27j and 27k.**




Figure 27j.



Figure 27k.

Step 11. Watch for sooting for 30 minutes. If sooting is present, adjust media and/or logs to eliminate.





Figure 27l.

Operation

Operation



For Your Safety - READ BEFORE LIGHTING:



A. This appliance is equipped with an ignition system that lights the pilot burner automatically. Do not attempt to light the pilot by hand.

B. BEFORE LIGHTING smell all around the appliance area for gas. Be sure to smell next to the floor because some gas is heavier than air and will settle on the floor.

What To Do If You Smell Gas:

- Do not try to light any appliance.
- Do not touch any electrical switch; do not use any phone in your building.
- Immediately call your gas supplier from a neighbour's

SIT Proflame 2 Electronic Ignition

phone. Follow the gas supplier's instructions.


- If you cannot reach your gas supplier, call the Fire Department.

C. Use only your hand to push in or turn the gas control knob. Never use tools. If the knob will not push in or turn by hand, don't try to repair it, call a qualified service technician. Force or attempt to repair may result in a fire or explosion.

D. Do not use this appliance if any part has been under water. Immediately call a qualified service technician to inspect the appliance and to replace any part of the control system, and any gas control which has been under water.

Lighting Instructions:

1. STOP! Read the safety information above on this label.
2. Remove the lower Horizontal access panel.
3. Turn "ON" manual "ON/OFF" switch located below the horizontal access panel (if available).
4. Turn Incoming gas valve to the "ON" position.
5. Wait 5 minutes to clear out any gas. If you smell gas, STOP! Follow "B" in the safety information above on this label. If you don't smell gas, go to the next step.



SW1 = Programming Button

LED1 = Red Diagnostic Light

LED2 = Amber Programming Remote Control Light


Typical Control Module shown

6. Turn fireplace "ON" using wall switch or remote control.

7. If the Fireplace does not light, the System will cycle through two trials, (one minute audible clicking, thirty seconds of silence, and then another one minute of audible clicking). If the system locks out due to inadequate gas flow, refer to "Troubleshooting" in instruction guide.

8. After completion of the information in the Troubleshooting section, Repeat step 5.

9. If the system will not function correctly, follow the instructions "To Turn Off Gas To Appliance" and call your service technician or gas supplier.



To Turn Off Gas To Appliance:

1. Turn off fireplace using wall switch or remote control.
2. Remove the lower Horizontal access panel.
3. Turn the incoming gas control valve to "Off".
4. Replace the lower Horizontal access panel.



Operation

Remote Operation

The Proflame 2 System consists of the following elements:

1. Pilot Assembly
2. Proflame Gas Valve.
3. Proflame 2 Control Module
4. Wiring Harness
5. Variable Speed fans
6. Variable Accent Lights
7. Proflame 2 remote control
8. Battery Pack
- 9 Manual override switch

NOTE: Can not be used with home automation systems.


The Proflame 2 Transmitter controls the following fireplace functions:

1. Main Burner On/Off
2. Main Burner flame modulation (6 levels).
3. Choice of standing or intermittent pilot (CPI/IPI).
4. Thermostat and Smart thermostat functions.
5. Variable Accent light (6 Levels).
6. Fan speed modulation (6 levels).

The Proflame 2 Transmitter uses a streamlined design with a simple button layout and informative LCD display. A Mode Key is provided to index between the features and a Thermostat Key is used to turn On/Off or index through Thermostat functions, see Figure 28. Additionally, a Key Lock feature is provided.



Figure 28.



SW1 = Programing Button

LED1 = Red Diagnostic Light

LED2 = Amber Programing Remote Control Light

Figure 28a. Proflame 2 Control Module



WARNING

Do not expose remote control to temperatures below 0°C (32°F) or above 50°C (122°F)



CAUTION

Property Damage Hazard. Excessive heat can cause property damage. The appliance can stay lit for many hours. Turn off the appliance if it is not going be attended for any length of time.




Figure 28b. Remote Control LCD Display

Operation



Initializing the System for the first time

1. Set master override switch to off position.
2. Install four (4) AA batteries into the battery holder.
3. Install three (3) AAA batteries in the back of the remote control.

Note the polarity of batteries and install them as indicated by the silk screen (+/-) on the holder.

4. Connect AC Power (115 volts, 60 Hz) to fireplace.

Operating the System for the first time

5. Press SW1 button on the control module. The control module will beep three (3) times and an amber LED is illuminated to indicate that the IFC is ready to synchronize with a remote control within 10 sec. Push the ON button. The control module will "beep" four (4) times to indicate transmitter's command is accepted.

The System is now initialized.



WARNING

Battery operated device. Read the battery instructions before installing them into the system. Do not expose any battery, or its holder, or a device in which batteries are installed, to a working temperature greater than 54°C / 129°F.



Figure 28c. Remote Control Battery Compartment

Temperature indication Display

With the system in the "Off" position, press the Thermostat Key and the Mode Key at the same time. Look at the LCD screen on the Remote Control to verify that a C or F is visible to the right of the Room Temperature display.




Figure 28d. Remote Control display in Fahrenheit & Celsius.

Turn On the Fireplace

With the system Off, turn the master override switch to on and press the On/Off Key on the Remote Control. The Remote Control display will show some other active Icons on the screen. **At the same time the Control Module will activate the fireplace. A single "beep" from the Control Module will confirm reception of the command.**

Turn Off the Fireplace

With the system On, press the On/Off Key on the Remote Control. The Remote Control LCD display will only show the room temperature. At the same time the Control Module will turn off the fireplace. **A single "beep" from the Receiver confirms reception of the command.**



Figure 28e. Remote Control Display



Operation

Remote-Flame Control

When you turn on the fireplace it starts on high. The proflame 2 has six (6) flame levels. Each time you press the Down Arrow Key once the flame height will reduce by one step.

You can continue this until the main burner flame turns off. You can still operate the accent lights and fans in this mode.

If the main burner flame is off and you press the up arrow key once, the flame will automatically go to high.




Figure 28f. Flame Off and Flame Level 1.




Figure 28g. Flame Level 5 and Flame Level Maximum.

Room Thermostat (Remote Control Operation)

The Remote Control can operate as a room thermostat. The thermostat can be set to a desired temperature to control the comfort level in a room. To activate the function, press the Thermostat Key, see Figure 28h. The LCD display on the remote control will change to show that the room thermostat is "On" and the set temperature is now displayed. To adjust the set temperature press the Up or Down Arrow Keys until the desired set temperature is displayed on the LCD screen of the Transmitter.




Figure 28h. Setting Room Thermostat

Smart Thermostat (Remote Control Operation)

The Smart Thermostat function adjusts the flame height in accordance to the difference between the set point temperature and the actual room temperatures. As the room temperature gets closer to the set point the Smart Function will modulate the flame down. To activate the function, press the Thermostat Key, see Figure 28, until the word "SMART" appears to the right of the temperature bulb graphic, see Figure 28i.

NOTE: When smart Thermostat is activated, manual flame height adjustment is disabled.




Figure 28i. Smart flame function

Operation



Disabling Thermostat

Some jurisdictions and bedroom installations require the thermostat to be disabled.

1. Partially take out one battery, see Figure 28j.
2. Insert the battery while holding down the thermostat button. The remote screen will display 'Clr' while the button is held down. See Figure 28k.
3. To enable thermostat repeat steps 1-2. The remote screen will display 'set' while the thermostat button is held down.



Figure 28j.



Figure 28k.

Fan Speed Control

The fireplace is equipped with optional hot air circulating fans. The speed of the fans can be controlled by the Proflame system. The fan speed can be adjusted through six (6) speeds. To activate this function use the Mode Key, see Figure 28, to index to the fan control icon, see Figure 28l. Use the Up/Down Arrow Keys to turn on, off, or adjust the fan speed. A single "beep" will confirm reception of the command.




Figure 28l. Fan Speed Control

Accent Light Control

If the fireplace is equipped with variable accent lights. The accent light function controls the Accent Lights. To activate this function use the Mode Key, see Figure 28, to index to the accent light icon, see Figure 28m.

Pressing the Up Arrow Key will turn the light on at the lowest setting. Continue pressing up to get brighter. Pressing the Down Arrow Key will turn the lights down until you get to the off position. A single beep will confirm the reception of the command.




Figure 28m. Light Control



Operation

Continuous Pilot (CPI) Selection (Optional)

In cold weather climates, the pilot burner can stay on continuously to prevent condensation or cold air temperatures **near the fireplace glass**. **Note, some jurisdictions do not permit use of continuous pilot system.** Check local codes or contact your Montigo dealer.

With the system in "off" position press the Mode Key, see Figure 28, to index to the CPI mode icon, see Figure 28n. Pressing the Up Arrow Key will activate the Continuous Pilot Ignition mode (CPI). Pressing the Down Arrow Key will return to IPI. A single "beep" will confirm the reception of the command.

NOTE:

- Requires CPI/IPI jumper cable installed, see page 19.




Figure 28n. Continuous Pilot / Intermittent Pilot Selection

Key Lock

This function will lock the keys to avoid unsupervised operation. To activate this function, press the Mode and Up Keys at the same time, see Figure 28o. To de-activate this function, press the Mode and Up Keys at the same time.




Figure 28o. Key Lock

Low Battery Power Detection

The life span of the batteries depends on various factors: quality of the batteries used, the number of ignitions of the appliance, the number of changes to the room thermostat set point, etc.

Remote Control

When the Remote Control batteries are low, a Battery Icon will appear on the LCD display of the Remote Control, see Figure 28p, before all battery power is lost. When the batteries are replaced this icon will disappear.




Figure 28p. Low Battery Power Detection

Control Module

When the back-up batteries are low, a "double-beep" will be emitted from the IFC when it receives an On/Off command from the Remote Control. This is an alert for a low battery condition of the receiver and after that no more commands will be accepted. When the batteries are replaced the "beep" will be emitted from the receiver as soon as powered.

Maintenance

Maintenance



Lighting Instructions *See page 29.*

General

Have the fireplace and installation inspected yearly. The inspection must include, but is not limited to, the following:

- A visual check of the entire vent system and termination.
- **An inspection of the explosion relief flappers and the door gaskets to ensure a proper seal.**
- An inspection of the burner, vent run, and primary air openings.
- An inspection of the gas valve, gas components, and pilot flame. **For your convenience a 1/8" manifold pressure tap is supplied on the gas valve for a test gauge connection**
- Inspection of all equipment; fans, thermostats, etc.
- For Natural Gas this appliance requires a minimum inlet pressure of 5.5" W.C. and a manifold pressure of 3.5" W.C.
- For Propane Gas this appliance requires a minimum inlet pressure of 11" W.C. and a manifold pressure of 10" W.C.
- **Always keep the fireplace area clear and free of combustible materials, as well as gasoline and other flammable vapours and liquids.**
- Do not use this appliance if any part has been under water. **Immediately call a qualified service technician to inspect the appliance and to replace any part of the control system and any gas control which has been under water.**
- Inspection of glass doors and screens for damage and proper installation.

Cleaning

When the fireplace is first activated, there may be some smoke and a visible film may be left on the glass. This is a normal condition, and is the result of burning of protective coatings on new metal.

- **Glass must be cleaned periodically to remove any film** (which is a normal by-product of combustion) which may be visible. Film can easily be removed by removing the door, as shown on Page 23. Handle the door carefully, and clean it with nonabrasive glass cleaners. One of the most effective products is Kel Kem.
- **Silicone seals on inner door during initial firing will "off gas",** leaving a visual deposit of a white substance on combustion chamber walls. This can easily be removed from the chamber walls using normal household products.
- Use a vacuum cleaner or whisk broom to keep the control compartment, burner, and firebox free from dust and lint.

NOTICE

Do not use ammonia based or abrasive cleaners on the glass, they will permanently etch the surface. Use an approved gas fireplace glass cleaner such as Kel-Kem or White off.

Pilot Burner Adjustment.

1. **Locate Pilot Adjustment Screw.** (See figure 29)
2. **Adjust pilot screw to provide properly sized flame as shown.**
3. After installing or servicing, leak test with a soap solution with main burner on. Coat pipe and tubing joints, gasket etc. with soap solution. Bubbles indicate leaks. Tighten any areas where the bubbles appear until the bubbling stops completely.




Figure 29. 'Hi-Lo' Adjustment on the SIT Proflame 2 gas valve.



Maintenance

Replacing Light Bulbs

The P38DF* light bulbs can be replaced in a few simple steps. Follow the directions for removing the door on page 23. Once the door has successfully been removed, proceed with figures 30 - 30b.



Figure 30. Remove the up-lighting glass from the burner tray.



Figure 30a. Wear gloves when handling light bulbs. To remove a light bulb, pull connecting wire away from bulb and pull light bulb up. Replace with new light bulb.



Figure 30b. Rotate newly replaced bulbs in a full circle. Place glass cover back in the burner tray.

Troubleshooting:

SIT Proflame 2:

The following is a troubleshooting chart of possible problems:

| PROBLEM | SOLUTION |
|---|---|
| Pilot won't ignite or spark. | <ul style="list-style-type: none"> - Check the on the batteries on the remote or the receiver. - Check the green LED on AC adaptor - Check the green ground wire under the valve |
| Main burner will not light. | <ul style="list-style-type: none"> - Check the wiring on the valve as per diagram |
| One or more light bulbs are not working | <ul style="list-style-type: none"> - Contact the local dealer for repairs or service |
| Fan not working | <ul style="list-style-type: none"> - Make sure the fan speed control is on. - 10 minute delay to turn on. |

If your fireplace still does not operate correctly, consult your local Montigo dealer.

All service and repairs should be performed by a qualified Technician.

All spare parts, optional fans, and optional trim finishes are available from your local Montigo dealer.


Appendix

Replacement Parts:

| Replacement Parts List - SIT IPI Proflame 2 | |
|---|------------|
| | P38DF |
| NG Gas Valve (with stepper motor) | RGC3033 |
| LP Gas Valve (with stepper motor) | RGC3034 |
| NG Pilot Assembly | RPA035 |
| LP Pilot Assembly | RPA036 |
| Ignitor Probe Assembly | RGC3075 |
| Flame sensor rod assembly | RGC3076 |
| Pilot Tubing | RPTA03 |
| Door | RDRP38 |
| Control Module | RGC3061 |
| Proflame Transmitter | RGC3063 |
| Tungsten Halogen Lamp | REC1319 |
| Replacement Screen | RSCP38 |
| Designer Speckled Stones | RR250SS |
| Driftwood Log Set | LGSPseries |

Appendix

Appendix A: Venting Terminations



| | Location | Canada* | USA** |
|---|---|--|--|
| A | clearance to the termination frame above grade, veranda, porch, deck, or balcony | 12 inches | 12 inches |
| B | clearance to top of doors or operable windows | 12 inches | 12 inches |
| C | clearance to sides or bottom of door or operable windows | 12 inches | 9 inches |
| D | clearance to permanently closed window when installed with approved glass penetration termination | 0 | 0 |
| E | clearance to permanently closed window Recommended to prevent condensation | 16 inches | 16 inches |
| F | clearance to ventilated soffit located within a horizontal distance to 24 inches from centerline of termination | 22 inches | 22 inches |
| G | clearance to unventilated soffit | 30 inches to combustibles 16 inches to non-combustibles | 30 inches to combustibles 16 inches to non-combustibles |
| H | clearance to outside corner | 9 inches | 9 inches |
| I | clearance to inside corner | 12 inches | 12 inches |
| J | clearance to each side of the vertical centerline of a metre or regulatory assembly to a maximum vertical distance of 15ft | 3 feet | 3 feet |
| K | clearance to service regulator vent outlet | 3 feet | 3 feet |
| L | clearance to non mechanical air supply inlet to the building or combustion air inlet to other appliance for appliance ≤ 100,000 BTU/H (30 KW) | 12 inches | 12 inches |
| M | clearance to forced air supply inlet | 6 feet | 3 feet above air inlet |
| N | clearance above paved sidewalk or paved driveway located on public property | 7 feet | 7 feet |
| P | clearance under veranda, porch, deck, or balcony | 22 inches to combustibles 16 inches to non-combustibles | 22 inches to combustibles 16 inches to non-combustibles |
| Q | clearance above roof | 2 feet | 2 feet |
| R | clearance to adjacent walls and neighboring buildings | 2 feet | 18 inches |
| S | clearance from corner in recessed location | 12 inches | 12 inches |
| T | Maximum depth of recessed location | 4 feet | 4 feet |
| U | Maximum width for back wall of recessed location | 2 feet | 2 feet |
| V | Horizontal clearance between two terminations that are level | 0 | 0 |
| W | Horizontal clearance (centre to centre) between two terminations that are not level | 18 inches | 18 inches |

Note 1: For N a vent shall not terminate directly above the sidewalk or paved driveway which is located between two single family dwellings and serve both dwelling.

Note 2: For P only permitted if veranda, porch, deck, or balcony is fully open on a minimum of two sides beneath the floor

Note 3: For J, K, and as specified in CGA B149 installation code. Local codes or regulations may vary.

* Based on CGA B149.1 Natural Gas and Propane installation code. Local codes may vary, please check with local regulatory agency.

** Based on ANSI Z223.1/NFPA 54 National Fuel Gas Code. Local codes may vary, please check with local regulatory agency.

Appendix

Appendix B: Warranty

The Warranty

The Companies warrants the Montigo Gas Appliance to be free from defects in materials and workmanship at the time of manufacture. On the Montigo fireplace, there is a ten-year warranty on the firebox and its components, a five-year warranty on the main burner and pilot burner, and a one-year warranty on the gas control valve, fibre logs and Power Vent Module. The Glass, plated / painted finishes, and refractory lining are exempt from the warranty.

Remedy And Exclusions

The coverage of this Warranty is limited to all components of the Gas Appliance manufactured by The Companies.

This Warranty only covers Montigo Gas Appliances installed in the United States or Canada.

If the components of the Gas Appliance covered by this Warranty are found to be defective within the time frame stated (see The Companies right of investigation outlined below). The Companies will, at its option, replace or repair defective components of the Gas Appliance manufactured by The Companies at no charge, and will also pay for reasonable labour costs incurred in replacing or repairing components. If repair or replacement is not commercially practical, The Companies will, at its option, refund the purchase price of the Montigo Gas Appliance.

This Warranty covers only parts and labour as provided above. In no case shall The Companies be responsible for materials, components, or construction which are not manufactured or supplied by The Companies, or for the labour necessary to install, repair or remove such materials, components or construction. All replacement or repair components will be shipped F.O.B. the nearest The Companies factory.

Qualifications To The Warranty

The Gas Appliance Warranty outlined above is further subject to the following qualifications:

- (1) The Gas Appliance must be installed in accordance with The Companies installation instructions and local building codes. The Warranty on this Montigo Gas Appliance covers only the component parts manufactured by The Companies. The use of components manufactured by others with this Montigo Gas Appliance could create serious safety hazards, may result in the denial of certification by recognized national safety agencies, and could be in violation of local building codes. This warranty does not cover any damages occurring from the use of any components not manufactured or supplied by The Companies
- (2) The Montigo Gas Appliance must be subjected to normal use. The Gas Appliances are designed to burn gas only. Burning conventional fireplace fuels such as wood, coal or any other solid fuel will cause damage to the Gas Appliance, will produce excessive temperatures and will result in a fire hazard.

Limitations On Liability

It is expressly agreed and understood that The Companies sole obligation, and purchaser's exclusive remedy under this Warranty, under any other warranty, expressed or implied, or in contract, tort or otherwise, shall be limited to replacement, repair, or refund, as specified above.

In no event shall The Companies be responsible for any incidental or consequential damages caused by defects in its products, whether such damage occurs or is discovered before or after replacement or repair, and whether or not such damage is caused by The Companies negligence. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you. The duration of any implied warranty with respect to this Montigo Gas Appliance is limited to the duration of the foregoing warranty. Some states do not allow limitation on how long an implied warranty lasts, so the above may not apply to you.

Investigation Of Claims Against Warranty

The Companies reserves the right to investigate any and all claims against this Warranty and to decide upon method of settlement.

The Companies Are Not Responsible For Work Done Without Written Consent

The Companies shall in no event be responsible for any warranty work done without first obtaining The Companies written consent.

Dealers Have No Authority To Alter This Warranty

The Companies employees and dealers have no authority to make any warranties nor to authorize any remedies in addition to or inconsistent with those stated above.

How To Register A Claim Against Warranty

In order for any claim under this Warranty to be valid, The Companies must be notified of the claimed defect in writing or by telephone, as soon as reasonably possible after the defect is discovered. Claims against this Warranty in writing should include the date of installation, and a description of the defect.

Other Rights

This Warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

NOTE: The Companies as stated above refer to - Canadian Heating Products Inc. and/or Montigo Del Ray Corp.

Canadian Heating Products Inc. and/or Montigo DelRay Corp. reserves the right to make changes at any time, without notice, in design, materials, specifications, prices and also to discontinue colors, styles and products.

Appendix

Appendix C: State of Massachusetts

Amendment

(Gas Fireplace / Equipment sold in the State of Massachusetts)

5.08: Modifications to NFPA-54, Chapter 10

(1) Revise NFPA-54 section 10.5.4.2 by adding a second exception as follows:

Existing chimneys shall be permitted to have their use continued when a gas conversion burner is installed, and shall be equipped with a manually reset device that will automatically shut off the gas to the burner in the event of a sustained back-draft.

(2) Revise 10.8.3 by adding the following additional requirements:

(a) For all side wall horizontally vented gas fueled equipment installed in every dwelling, building or structure used in whole or in part for residential purposes, including those owned or operated by the Commonwealth and where the side wall exhaust vent termination is less than seven (7) feet above finished grade in the area of the venting, including but not limited to decks and porches, the following requirements shall be satisfied:

1. INSTALLATION OF CARBON MONOXIDE DETECTORS. At the time of installation of the side wall horizontal vented gas fueled equipment, the installing plumber or gas fitter shall observe that a hard wired carbon monoxide detector with an alarm and battery back-up is installed on the floor level where the gas equipment is to be installed. In addition, the installing plumber or gas fitter shall observe that a battery operated or hard wired carbon monoxide detector with an alarm is installed on each additional level of the dwelling, building or structure served by the side wall horizontal vented gas fueled equipment. It shall be the responsibility of the property owner to secure the services of qualified licensed professionals for the installation of hard wired carbon monoxide detectors

a. In the event that the side wall horizontally vented gas fueled equipment is installed in a crawl space or an attic, the hard wired carbon monoxide detector with alarm and battery back-up may be installed on the next adjacent floor level.

b. In the event that the requirements of this subdivision can not be met at the time of completion of installation, the owner shall have a period of thirty (30) days to comply with the above requirements; provided, however, that during said thirty (30) day period, a battery operated carbon monoxide detector with an alarm shall be installed.

2. APPROVED CARBON MONOXIDE DETECTORS. Each carbon monoxide detector as required in accordance with the above provisions shall comply with NFPA 720 and be ANSI/UL 2042 listed and IAS certified.

3. SIGNAGE. A metal or plastic identification plate shall be permanently mounted to the exterior of the building at a minimum height of eight (8) feet above grade directly in line with the exhaust vent terminal for the horizontally vented gas fueled heating appliance or equipment. The sign shall read, in print size no less than one-half (1/2) inch in size, "GAS VENT DIRECTLY BELOW. KEEP CLEAR OF ALL OBSTRUCTIONS".

4. INSPECTION. The state or local gas inspector of the side wall horizontally vented gas fueled equipment shall not approve the installation unless, upon inspection, the inspector observes carbon monoxide detectors and signage installed in accordance with the provisions of 248 CMR 5.08(2)(a)1 through 4.

(b) EXEMPTIONS: The following equipment is exempt from 248 CMR 5.08(2)(a)1 through 4:

1. The equipment listed in Chapter 10 entitled "Equipment Not Required To Be Vented" in the most current edition of NFPA 54 as adopted by the Board; and

2. Product Approved side wall horizontally vented gas fueled equipment installed in a room or structure separate from the dwelling, building or structure used in whole or in part for residential purposes.

(c) **MANUFACTURER REQUIREMENTS - GAS EQUIPMENT VENTING SYSTEM PROVIDED.** When the manufacturer of Product Approved side wall horizontally vented gas equipment provides a venting system design or venting system components with the equipment, the instructions provided by the manufacturer for installation of the equipment and the venting system shall include:

1. Detailed instructions for the installation of the venting system design or the venting system components; and

2. A complete parts list for the venting system design or venting system.

(d) **MANUFACTURER REQUIREMENTS - GAS EQUIPMENT VENTING SYSTEM NOT PROVIDED.** When the manufacturer of a Product Approved side wall horizontally vented gas fueled equipment does not provide the parts for venting the flue gases, but identifies "special venting systems", the following requirements shall be satisfied by the manufacturer:

1. The referenced "special venting system" instructions shall be included with the appliance or equipment installation instructions; and

2. The "special venting systems" shall be Product Approved by the Board, and the instructions for that system shall include a parts list and detailed installation instructions.

(e) A copy of all installation instructions for all Product Approved side wall horizontally vented gas fueled equipment, all venting instructions, all parts lists for venting instructions, and/or all venting design instructions shall remain with the appliance or equipment at the completion of the installation.

(3) After NFPA-54 section 10.10.4.2 add a new section 10.10.4.3 as follows:

When more than four gas appliances are to be vented through a common gas vent or common horizontal vent manifold, a plan of the proposed vent installation shall be submitted to the Inspector and the serving gas supplier for review and approval.

Notes

Notes



P38DF

Single Sided Gas Fireplace

