
LOG SET IMPORTANT INFORMATION






This instruction contains recommended log placement for your Real Fyre log set. This instruction contains recommended log placement for these Real Fyre logs which will promote good combustion and provide superior flame pattern and appearance, when the logs are used with a Peterson burner system. Adequate ventilation is absolutely necessary! Provided significant, noticeable sooting does not occur, some flexibility is possible in log placement to suit your individual preference (see Important below). If you experience a continued accumulation of black carbon (soot) on your logs it is an indication of incomplete combustion and you should move the effected log(s) so as to minimize the flame contact on the effected log(s). Please read these instructions completely and carefully.



Important: Adequate ventilation is absolutely necessary. Adequate spacing between the logs is NECESSARY and MUST be maintained. Some carbon build up (sooting) may occur where flames strike the logs. If carbon build up (sooting) continues, rearrange top logs to allow more opening(s) for flame(s) before sooting becomes worse. If any sooting occurs outside of the firebox (i.e. on the walls), turn off unit immediately and contact a qualified professional service technician.


WARNING: Use ONLY Real Fyre burners and valves with this Real Fyre gas log set. Failure to do so may result in property damage or personal injury, and will void listings, certifications, and invalidate claims made to RHP. Contact your local Real Fyre dealer if you need more information.

This product is only warranted when used as part of a Robert H. Peterson Co. vented burner system.



Golden Oak Designer Plus (RDP) Log Placement Instructions (12" model)


Ι



CAUTION: Burn hazard! Logs will remain hot for some time after use.











Golden Oak Designer Plus (RDP) Log Placement Instructions (16" & 19" models)




CAUTION: Burn hazard! Logs will remain hot for some time after use.











Golden Oak Designer Plus (RDP) Log Placement Instructions (18" & 20" models)



CAUTION: Burn hazard! Logs will remain hot for some time after use.













Golden Oak Designer Plus (RDP) Log Placement Instructions (24" & 30" models)





CAUTION: Burn hazard! Logs will remain hot for some time after use.













Golden Oak Designer Plus (RDP) Log Placement Instructions (36" model)



CAUTION: Burn hazard! Logs will remain hot for some time after use.


2 Boxes	Items
RDP-36BF	RDP-36BF
RDP-36T/R	RDL-15TL, RDL-15TR, RDL-20T, RDL-30BR, RDL-9TL, RDL-9TR












Golden Oak Designer Plus (RDP) Log Placement Instructions (42" model)




CAUTION: Burn hazard! Logs will remain hot for some time after use.


3 Boxes	Items
RDP-36BR	RDP-36BR
RDP-42B	RDP-42B
RDP-42T	RDL-15TL, RDL-15TR, RDL-18TL, RDL-18TR, RDL-24T












Golden Oak Designer Plus (RDP) Log Placement Instructions (48", 54", & 60" models)



CAUTION: Burn hazard! Logs will remain hot for some time after use.

R-48 box details		
3 Boxes	Items	
RDP-42B	RDP-42B	
RDP-48B	RDP-48B	
RDP-48T	RDL-18TL, RDL-18TR, RDL-24T, RDL-24T, RDL-30T	

R-54 box details		
3 Boxes	Items	
RDP-48B	RDP-48B	
RDP-54B	RDP-54B	
RDP-48T	RDL-18TL, RDL-18TR, RDL-24T, RDL-24T, RDL-30T	

R-60 box details		
3 Boxes	Items	
RDP-54B	RDP-54B	
RDP-60B	RDP-60B	
RDP-48T	RDL-18TL, RDL-18TR, RDL-24T, RDL-24T, RDL-30T	

Ι

